

پیکربندی مودم netxone

برای ارتباط از طریق Web با دستگاه از IP: 192.168.0.1 استفاده می‌کنیم.



<input type="text" value="Username"/>
<input type="password" value="Password"/>
<input type="button" value="Login"/>

Username و password پیش‌فرض دستگاه **root** می‌باشد.

پس از ورود در صفحه اصلی از منوی سمت راست بخش **BASIC** را انتخاب می‌کنیم.

در این بخش **Transfer Mode** را در حالت **PTM**، **STU Mode** را در حالت **STU-R** و **Mode** را در حالت **Bridge** قرار می‌دهیم.

BASIC

G.SHDSL

Transfer Mode	PTM	
Pair Mode	PAIR-1	
STU Mode	STU-R	

WAN

Mode	Bridge	
------	--------	--

LAN

IP Address	192.168.0.1
Subnet Mask	255.255.255.0

Default Gateway

IP Address	0.0.0.0
------------	---------

* Note: Either the G.Shdsl mode or the WAN mode is changed, that The system will need to reboot !!



در پایان با کلیک بر روی Apply تغییرات را اعمال می‌کنیم. سپس باید مودم را Restart کنیم برای این منظور از به قسمت **UTILITY----->RESTART** رفته و مودم را Restart می‌کنیم.

NETXONE

G.Shdsl.bis

Info Ready

INFORMATION

Device Information

Model Name	xprime 2010
HW MCSV	145C-0067-01829AE5
SW MCSV	147A-0067-01929B3A
Software Version	019
Ethernet MAC Address	00:02:AB:21:8A:49
Serial Number	BKLX83Q50001
DSL Chip Name	PEF21628V1.2
DSL Hardware Pair Number	1
DSL Firmware Version	1.1-1.9.0_001_eLP
System Current Time	2017/01/01 01:46:01
System Up Time	0 day 1 hr 46 min 20 sec

NETXONE

G.Shdsl.bis

Info Ready

UTILITY - RESTART

System Reboot

Click Restart to reboot device, waiting a minute and will redirect to Login page.

Restart